







Recommended Minimum Spare Parts List 50PF NG Fusion Furnace

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|---|---|-----------------------------|--------------------|
|  | Air Pressure Switch DG10-3 1-10mbar | 1 | RF341APS |
|  | Blower Assembly Aerotech 4 Pole (220 – 240V) (NG & Oil) | 1 | PFAERO4P |
|  | Burner Assembly for 25PF Natural Gas/Oil Furnace | 1 | PF325PFA |
|  | Burner Controller LFL1.1635 | 2 | RF336LFL |
|  | Ceramic Anchor 3" (Complete Assembly) (Set of 8) | 2 | PC128008 |
|  | Foot Pedal (Festo) | 1 | RF357FFP |
|  | Furnace Tile, 700 x 610 x 22mm (Suit 25 & 50PF Furnace) | 10 | LFT70022 |
|  | Gas Pilot Burner (Natural Gas) 56 Air 9-64 (W) | 1 | PF339GPB |
|  | Gas Pressure Switch(Low) DG50N | 1 | RF363PSW |
|  | Ignition Lead (Copper Cord) (Per metre) | 5 | RF217000 |





Recommended Minimum Spare Parts List 50PF NG Fusion Furnace

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|--|--|-----------------------------|--------------------|
|  | Ignition Transformer, TC1LVCA | 1 | RTC1L926 |
|  | Superwool Ceramic Fibre Blanket 25mm 7.6m x 610mm | 1 | JB128025 |
|  | Solenoid Valve, Pilot (NG) DIN Plug | 1 | RF210FF7 |
|  | Spark Plug (Igniter) (NG & Oil) | 2 | RF338SPI |
|  | Speed Controller ABB 0.75KW | 1 | RF37775C |
|  | Temperature Controller RKC100CB | 1 | RF381RKC |
|  | Thermocouple Element, Type K. 310mm | 6 | PF201FF1 |
|  | Thermocouple Head (1/2") | 1 | RJB35TCH |
|  | Thermocouple Sheath (Inconel) | 4 | PF203FF2 |
|  | Toggle Switch On/Off, High/Low | 1 | RA93A401 |

Recommended Minimum Spare Parts List 50PF NG Fusion Furnace

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|--|--|---------------------------------|--------------------|
|  | U.V. Amp Meter | 1 | RF373UVA |
|  | U.V. Cell, (Flame Detector) QRA.2 | 4 | RF204FF3 |
| | Valve Train, Natural Gas 240V | 1 | RF352NGV |
| | Parts Packaging & ISPM15 Certified Wood Crate | 1 | ZZPCRATE |



Recommended Minimum Spare Parts List 50PF NG Fusion Furnace CANADA

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|---|---|-----------------------------|--------------------|
|  | Air Pressure Switch Honeywell C6097A1004 | 1 | RFAPSHON |
|  | Aero-Tech 110v Baldur Motor Comb Air Fan | 1 | RFBALDMR |
|  | Burner Assembly for 25PF Natural Gas/Oil Furnace | 1 | PF325PFA |
|  | Burner Controller, LFL 1.635 110 Volt | 2 | RF110LFL |
|  | Ceramic Anchor 3" (Complete Assembly) (Set of 8) | 1 | PC128008 |
|  | Foot Pedal (Festo) | 1 | RF357FFP |
|  | Furnace Tile, 700 x 610 x 22mm (Suit 25 & 50PF Furnace) | 10 | LFT70022 |
|  | Gas Pilot Burner (Natural Gas) 56 Air 9-64 (W) | 2 | PF339GPB |
|  | Low Gas Pressure Switch Honeywell C6097A1012 Man Reset 3-21"WC | 2 | RFLPS97A |
|  | Ignition Lead (Copper Cord) (Per metre) | 5 | RF217000 |

Recommended Minimum Spare Parts List 50PF NG Fusion Furnace CANADA

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|--|--|---------------------------------|--------------------|
|  | Ignition Transformer TZI7 5-20/33R | 2 | RFITTZ17 |
|  | Superwool Ceramic Fibre Blanket 25mm 7.6m x 610mm | 1 | JB128025 |
|  | Pilot Solenoid Valve 110v Krom Schroder VAS110 | 2 | RFVAS110 |
|  | Spark Plug (Igniter) (NG & Oil) | 2 | RF338SPI |
|  | Temperature Controller RKC100CB | 1 | RF381RKC |
|  | Temperature Controller RKC O/T SA100 DIN Rail Mount | 1 | RF382RKC |
|  | Thermocouple Element, Type K. 310mm | 6 | PF201FF1 |
|  | Thermocouple Head (1/2") | 1 | RJB35TCH |
|  | Thermocouple Sheath (Inconel) | 4 | PF203FF2 |
|  | Toggle Switch On/Off, High/Low | 1 | RA93A401 |

Recommended Minimum Spare Parts List 50PF NG Fusion Furnace CANADA

| <i>Image</i> | <i>Description</i> | <i>Suggested Stock Qty.</i> | <i>Part Number</i> |
|--|--|---------------------------------|--------------------|
|  | U.V. Amp Meter | 1 | RF373UVA |
|  | U.V. Cell, (Flame Detector) QRA.2 | 4 | RF204FF3 |
| | Valve Train, Natural Gas 110 Volt | 1 | RF110NGV |
| | Parts Packaging & ISPM15 Certified Wood Crate | 1 | ZZPCRATE |