









Recommended Minimum Spare Parts List MFD NG Cupellation Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Air Pressure Switch DG10-3 1-10mbar	1	RF341APS
	Blower Assembly Aerotech 4 Pole (220 – 240V) (NG & Oil)	1	PFAERO4P
	Burner Assembly for 25PF Natural Gas/Oil Furnace	1	PF325PFA
	Burner Controller LFL1.1635	2	RF336LFL
	Ceramic Anchor 3" (Complete Assembly) (Set of 8)	1	PC128008
	Foot Pedal (Festo)	1	RF357FFP
	Furnace Tile, 560 x 470 x 22mm (Suit No. 5 & 6 Muffle)	10	LFT56022
	Gas Pilot Burner (Natural Gas) 56 Air 9-64 (W)	1	PF339GPB
	Gas Pressure Switch(Low) DG50N	1	RF363PSW
	Ignition Lead (Copper Cord) (Per metre)	5	RF217000
	Ignition Transformer, TC1LVCA	1	RTC1L926

Recommended Minimum Spare Parts List MFD NG Cupellation Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Muffle No.5 Large "D" Mould, Slotted Vent	2	FMUFFLW5
	Superwool Ceramic Fibre Blanket 25mm 7.6m x 610mm	1	JB128025
	Solenoid Valve, Pilot (NG) DIN Plug	1	RF210FF7
	Spark Plug (Igniter) (NG & Oil)	2	RF338SPI
	Speed Controller ABB 0.75KW	1	RF37775C
	Temperature Controller RKC100CB	1	RF381RKC
	Thermocouple Element, 230mm plus 75mm, Type "K"	6	PC101LCF
	Thermocouple Sheath (Inner) 250 x 10mm	4	RC102CFE
	Thermocouple Sheath (Outer) 250 x 15mm	4	RC103CFE
	Toggle Switch On/Off, High/Low	1	RA93A401
	U.V. Amp Meter	1	RF373UVA

Recommended Minimum Spare Parts List MFD NG Cupellation Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	U.V. Cell, (Flame Detector) QRA.2	4	RF204FF3
	Muffle No.5 Large "D" Mould, Slotted Vent	2	FMUFFLW5
	Vent Tube No.5 (Large Slotted) Suit Muffle No. 5 & 8	2	FTUBES05
	Valve Train, Natural Gas 240V	1	RF352NGV
	Parts Packaging & ISPM15 Certified Wood Crate	1	ZZPCRATE